

# MAINTENANCE AND WARRANTY GUIDE

## AQUAROLL® PRO SYSTEM



### INITIAL INSTALLATION

Professional installation of the Aquaroll® PRO system is highly recommended. Service and installation contracts are available, upon request.

Before initial usage, the water heater must be purged to eliminate air and fill with water. To accomplish, complete the following steps:

1. Press the "On/Off" power switch, to the "On" position (a red light will illuminate).
2. Press the "Water" supply button three (3) times, or until the "Hot" light comes on.
3. Take the shower hose and position it above the tank, facing inward.
4. Press the shower hose for roughly thirty (30) seconds, until water emerges.

Once the water heater has been purged, add up to two (2) bags of glass beads. Then add one (1) gallon of water and rotate for one (1) minute. Drain thoroughly, once completed.

- **Caution:** Glass beads must be thoroughly rinsed with one (1) gallon of water for one (1) minute prior to initial client use of the Aquaroll® PRO system.
- **Caution:** Only use glass beads supplied by Aquaroll®, as they are specially designed for full functionality.
- **Caution:** Do not exceed two and a half (2.5) bags of glass beads at one time in the system.
- **Note:** Fewer beads may be used when treating smaller extremities. The maximum quantity of beads may be utilized when treating large feet, such as with male athletes.

### STORAGE REQUIREMENTS

Always press the "On/Off" power switch to "Off" and unplug the device after each daily usage session.

Store the Aquaroll® PRO system in a moderate, dry location.

- **Caution:** Never store the Aquaroll® PRO system in a location with a temperature below fifty (50) degrees Fahrenheit.
- **Caution:** Never allow unattended children or mentally disabled clients around the Aquaroll® PRO system, as there is a risk of ingestion of glass beads.

It is recommended to cover the device, when not in use.

Where necessary to discard the Aquaroll® PRO system, ensure full compliance with local waste regulations.

### MAINTENANCE

The drainage valve of the tank must be cleaned quarterly, at a minimum. Refer to the Aquaroll® Care and Cleaning Instructions (90000007) for further details.

Glass beads require replacement after every thousand (1,000) treatment sessions. In the case of high-volume usage, this equates to every one to two (1-2) months.

- **Caution:** Failure to replace the glass beads can result in decreased client benefit, due to the loss of uniformity and constancy of the percussive hydro-massage. Such failure can also result in worn-down beads getting stuck inside the drainage and system tubing and can void the warranty.

### WARRANTY INFORMATION

The Aquaroll® PRO system comes with a one (1) year warranty on parts.

**The warranty is void upon the following conditions:**

- **improper use and/or evidence thereof**
- **attempted opening and/or repair of the machine by anyone other than the designated service professional**
- **loss of the original packaging**

**The parts warranty is not valid where the Aquaroll® PRO system is returned in packaging other than the original shipment packaging.**

Additional parts and labor warranties are available for purchase, upon request. Please contact AM Rejuvenation for details.

### AM Rejuvenation, LLC

6538 Collins Avenue, #313  
Miami Beach, FL 33141

To order or for info, call:  
305.504.9690

Find more info online:  
[www.aquarollUSA.com](http://www.aquarollUSA.com)

Request info by email:  
[sales@aquarollUSA.com](mailto:sales@aquarollUSA.com)